

⚠️ Prima di procedere a qualsiasi operazione di installazione accertarsi che la misura del box ordinato corrisponda alla dimensione del piatto installato. ⚠️



70400F porta saloon + 70600 parete fissa



Porta A=	A=	Fisso B=	B=
70401F	67-69*	70601	68-70
70402F	72-74*	70602	73-75
70403F	77-79*	70603	78-80
70404F	87-89*	70604	88-90
70405F	97-99*	70605	98-100
		70606	108-110
		70607	118-120



